

651 Hydrogen Sulfide Monitoring System



RUGGED FENCE-LINE HYDROGEN SULFIDE MONITORING

Heavy duty, reliable and versatile hydrogen sulfide monitoring—the Jerome® 651 monitoring system from AMETEK Arizona Instrument is designed to provide long-term, continuous monitoring even in rough weather conditions. Stationed on a pole, fence or wall, multiple units can be linked to form a perimeter monitoring system. The detachable, hand-held analyzer within the unit can be used to sweep an area and help pinpoint the source of a hydrogen sulfide leak or hot spot.

JEROME®



651 Hydrogen Sulfide Monitoring System



Hydrogen sulfide analysis for a wide range of applications.

FEATURES

PERIMETER MONITORING: Multiple Jerome® 651 units can be linked to form a perimeter monitoring system to help locate the source of H₂S and ensure safety and compliance.

DETACHABLE UNIT: Quickly and easily sweep an area for hydrogen sulfide hot spots with the detachable, hand-held Jerome® 631-X hydrogen sulfide analyzer.

GOLD FILM SENSOR: Validated in the field and in the lab for over 35 years, our proprietary gold film sensor ensures repeatable results across a wide range of applications.

WEATHER STATION: The attached weather station monitors outside temperature as well as wind speed and direction for increased accuracy in pinpointing the source of odor contamination.

DATA TRANSMISSION: Advanced data logging and radio telemetry capabilities make downloading data to a remote PC easy and convenient.

PC SOFTWARE: Intuitive PC software with user selectable time-weighted average reporting and a site view tab give users a bird's eye view of the monitoring system as a whole.

PROGRAMMABLE ALARMS: The 651 comes with programmable alarms that automatically send email alerts if H₂S levels rise above your specified upper limit.

TEMPERATURE CONTROLLED INTERIOR: Resistive heating and thermoelectric cooling keep the interior of the 651 at a consistent temperature for increased accuracy.

REGULATORY COMPLIANCE: The 651 is in active use by many regulatory agencies and landfill, water treatment and wastewater management facilities across the world.

RADIO MODEM SPECIFICATIONS

| | |
|-----------------------|---|
| Frequency | 2.4-2.4835 GHz (2400 MHz) 49 selectable channels |
| Serial Interface | RS-232 |
| Power Requirement | 10-30 VDC, 450 mA |
| Operating Temperature | -40°C to 75°C |
| Range | Up to 6.4 km (4 mile) "line of sight" Longer distances may be obtainable through use of a high gain antenna or by using the optional Radio Repeater |

SPECIFICATIONS

| | |
|-------------------------------|---|
| Detection Range | 3 ppb (0.003 ppm) to 50 ppm |
| Resolution | 0.001, 0.01, 0.1, and 1 ppm |
| Accuracy | ±0.005 ppm at 0.05 ppm ±0.05 ppm at 0.5 ppm ±0.5 ppm at 5 ppm ±2 ppm at 25 ppm |
| Sample Intervals | 1, 2, 5, 10, 15, 30, 60 or 120 minutes |
| Regeneration Intervals | 6, 12, 24 and 48 hours |
| Flow Rate | 150 mL/min |
| Operating Environment | -40°C to 55°C, non-explosive, 0-100% RH |
| Result Units | ppm, ppb |
| Data Storage Capacity | 50,000 test results |
| Power Requirements (651 Unit) | 100-120 VAC, 50/60 Hz, 7A or 210-240 VAC, 50/60 Hz, 4A |
| Control Board Fuse | Fast-acting IEC 1.6A 250V, 5 mm x 20 mm |
| Case Construction | Polyester with insulation to reduce heat transfer |
| Battery (Detached 631-X Unit) | Rechargeable NiCad 6 hour life |
| Estimated Sensor Life | 3 to 6 months depending on operating conditions |
| Display | 8 digit alphanumeric LCD |
| Output | Spectra Radio Analog: 4-20 mA passive current loop |
| Dimensions | 26" W x 25" H x 9" D (67 cm W x 64 cm H x 23 cm D) |
| Weight | 52 lbs. (24 kg) |
| Warranty | 1 year, factory parts and labor except for 631-X sensor |



An ISO 9001-2015 Registered Company
3375 N Delaware St. | Chandler, AZ 85225
(p) 800-528-7411 | (f) 602-281-1745
sales@azic.ametek.com | www.azic.com